

Ground-to-Components Index

NOTE: All ground wires are BLK unless otherwise noted.

Ground	Page	Component or Circuit Grounded
G1	14-8	Battery
G2	14-8	Engine block (left side)
G3	14-8	Engine block (left side)
G4	14-8	EPS gearbox
G101	14 and 14-1	CKP sensor, DLC, ECM (PG1 and PG2 are BLK; LG1 and LG2 are BRN/YEL), IAC valve, Ignition coils, Immobilizer receiver unit, PGM-FI main relay, VSS, VTEC oil pressure switch Shielding between the ECM and these components have BRN/YEL wires: CKP sensor, CMP sensor A, CMP sensor B, Knock sensor, Primary HO2S, Secondary HO2S
G201	14-2	A/C condenser fan motor, Blower motor relay, ELD unit, EPS control unit, Front parking light (right) ('00-'03), Front parking/side marker light (right) ('04-'05), Front turn signal light (right), Radiator fan motor, Right headlight (low beam) ('00-'03), Side turn signal light (right), Windshield washer motor
G301	14-3	Air pump relay, Brake fluid level switch, Cruise control actuator, Front parking light (left) ('00-'03), Front parking/side marker light (left) ('04-'05), Front turn signal light (left), Intermittent wiper relay ('02-'05), Left headlight (low beam) ('00-'03), Radiator fan switch, Side turn signal light (left), Windshield wiper motor
G302	14-3	Air pump
G303	14-3	ABS modulator-control unit (2 wires)
G351	14-8	EPS control unit
G401	14-4	Clutch interlock switch, Clutch pedal position switch, Combination light switch, DLC, Ignition key switch/key light, Intermittent wiper relay ('00-'01), Rear window defogger switch (removable hardtop) ('00 early production), Turn signal/hazard relay, Wiper/washer switch
G402	14-5	Blower power transistor, Convertible top control unit (3 wires), Cruise control unit, DRL control unit (Canada) (2 wires), EPS control unit, Heater control panel
G501	14-6	Convertible top control unit, Cruise control main switch, Driver's door key cylinder switch, Driver's door latch, Engine start switch, Gauge assembly (2 wires), Keyless door lock control unit, Left headlight (low beam) ('04-'05), Passenger's window switch, Power mirror switch, Power window master switch, Radio remote switch, Rear window defogger switch ('02-'05), Right headlight (low beam) ('04-'05)
G502	14-6	Audio unit ('04-'05: 2 wires)
G601	14-7	Accessory power socket, Driver's seat belt switch, Fuel tank unit (2 wires), High mount brake light, G901, Rear window defogger relay (removable hardtop) ('00-'01), Noise condenser ('02-'05), Rear window defogger (softtop) ('02-'05), Trunk lid latch, XM receiver (USA: '04-'05)
G602	14-7	Back-up light (left/right), Brake/side marker/taillight (left/right) ('04-'05), Brake/taillight (left/right) ('00-'03), License plate light, Rear side marker light (left/right), Rear turn signal light (left/right)
G801	14-8	SRS unit (2 wires)
G901	14-7	Rear window defogger relay ('00-'01), Rear window defogger switch ('00 late production and '01)
G902	14-7	Rear window defogger (removable hardtop)

©2005 American Honda Motor Co., Inc.