

Fuel and Emissions

– ECM Power and Ground

NOTE: See page 10-4 for details of Fuse 21.

