




Connector Terminal Views

7. Starter Solenoid

- Black
- Lower left side of engine
- On engine wire harness



1 BLK/WHT (Starter solenoid control (+))