




Connector Terminal Views

36. IAT Sensor

- Gray
- Left rear side of engine
- On engine wire harness



- 1 GRN/YEL (Circuit Z28 – Sensor ground)
2 RED/YEL (Sensor output (IAT))