




Connector Terminal Views

80. TP Sensor

- Gray
- Left front side of engine
- On engine wire harness



- 1 GRN/YEL (Circuit Z28 – sensor ground (SG2))
- 2 RED/BLK (Sensor output (TPS))
- 3 YEL/BLU (Circuit D46 – reference voltage (VCC2))