




Connector Terminal Views

84. Alternator

- Light Green
- Left front of engine
- On engine wire harness



- 1 BLK/YEL (Fuse 6)
- 2 WHT/GRN (Alternator control signal (ALTC))
- 3 WHT/BLU (Indicator light control)
- 4 WHT/RED (Alternator FR signal (ALTF))