




Connector Terminal Views

95. Engine Start Switch

- Green
- Left of steering wheel
- On dashboard wire harness A



- 1 BLU/WHT (Switch output (+))
- 2 BLK/WHT (Fuse 3)
- 3 BLK (G501)
- 4 —
- 5 —