

Connector to Harness Index

Dashboard Wire Harness B (right branch)

Ref	Connector or Terminal	Cavities/ Color	Location	Connects to	Notes
1	IG2 relay	5-GRY	Right side of steering column		
2	Accessory power socket relay	5-GRY	Right side of steering column		
3	PGM-FI main relay	7-BRN	Right side of steering column		
4	DRL diode	2-N/A	Under middle of dash		Canada
5	DRL control unit	14-N/A	Under middle of dash		Canada
6	Mode control motor	7-GRN	Under left middle of dash		
7	DLC	16-GRY	Under right middle of dash		'00-'01
8	Air mix control motor	7-GRN	Under right side of dash		
9	Evaporator temperature sensor	2-GRY	Under right side of dash		
10	Blower power transistor	5-NAT	Under right side of dash		
11	Convertible top control unit connector A	14-GRY	Under right side of dash		
12	Blower motor	2-NAT	Under right side of dash		
13	Recirculation control motor	7-GRN	Under right side of dash		
14	C203	7-BRN	Under right side of dash	Right-side engine compartment wire harness (see page 203-4)	
15	C201	16-LT BLU	Under right side of dash	Right-side engine compartment wire harness (see page 203-4)	
16	C451	16-LT BLU	Under right side of dash	Dashboard wire harness A (see page 203-12)	
17	G402			Body ground via dashboard wire harness B	
18	C452	2-GRY	Under right side of dash	Roof wire harness (see page 203-16)	
19	Convertible top motor emergency connector	2-GRY	Under right side of dash		
20	C202	6-LT BLU	Under right side of dash	Right-side engine compartment wire harness (see page 203-4)	
21	Parking brake switch	1-NAT	Below center console		'00-'03
21	Parking brake switch	2-GRY	Below center console		'04-'05
22	Hazard warning switch	10-GRY	Below center console		
23	Rear window defogger switch	5-GRN	Below center console		*
24	Convertible top switch	6-GRY	Below center console		
25	DLC	16-GRY	Under left middle of dash		'02-'05

* = '00-'01 Removable hardtop



Connector to Harness Index

